


Model 128i Base Positioning

In the DP /Oblique view rear hinge panel will be closed to cover the opening next to the imager



In the DP/Oblique view the "Wings" will be open so they are resting on the floor

In the Lateral view the rear hinge panel will be open and leaning against the "Upright" piece to keep it from hitting the wall



In the Lateral view the "Wings" will be closed covering the spaces to either side of the imager